

6

5

4

3

2

1

### WATER INTAKE KEY


	FRONT BALLAST INLET
	PORT REAR BALLAST INLET
	PORT REAR SUPPLEMENTAL BALLAST OUTLET (OPTIONAL EQUIPMENT)
	ENGINE INTAKE
	STBD REAR BALLAST INTAKE
	STBD REAR SUPPLEMENTAL BALLAST OUTLET (OPTIONAL EQUIPMENT)

#### NOTES:

- ENGINE WATER EXITS BOAT THROUGH SURF PIPE EXHAUST WHEN RUNNING
- RED HANDLE RAW WATER INTAKE BALL VALVE TO BE CLOSED IF DECONTAMINATING THROUGH FRESH WATER FLUSH & ENGINE RUNNING

### TOP VIEW

LOOKING DOWN




## GS20 SHOWN

GS22 SIMILIAR

RAW WATER INTAKE

### BOTTOM VIEW

LOOKING UP



PROJECT:	MODEL: GS20	MODEL YEAR: 2023
----------	-------------	------------------

TITLE:	<b>GS-SERIES WATER DECONTAMINATION DIAGRAM</b>	
--------	--	--

DO NOT SCALE DRAWING  
 PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS  
 THE SOLE PROPERTY OF NAUTIQUE BOAT COMPANY.  
 ANY REPRODUCTION IN PART OR AS A WHOLE  
 WITHOUT THE WRITTEN PERMISSION OF NAUTIQUE  
 BOAT COMPANY IS PROHIBITED.



SIZE	DWG. NO.	REV
C	128-201-AIS	A

SCALE:	1:18	SHEET 2 OF 2
--------	------	--------------

6

5

4

3

2

1